

Novergy User Manual Inverter IGPB-V-34KW



Contents

1 About this manual.....	5
1.1 Validity	5
1.2 Target group	5
1.3 Symbols used in this manual	6
2 Safety	7
2.1 Intended use.....	7
2.2 Safety standards	7
2.3 Important safety information	8
2.4 Symbols on the type label	10
2.5 Basic safety protection	11
3 Unpacking	12
3.1 Scope of delivery	12
3.2 Checking the delivery	12
4 Mounting	13
4.1 Ambient conditions.....	13
4.2 Mounting location	15
4.3 Mounting the inverter with the wall bracket	16
5 Electrical Connection	19
5.1 Safety.....	19
5.2 System layout of inverters without integrated DC-switch.....	21
5.3 Overview of the electrical connection area	22
5.4 AC connection	23
5.4.1 Conditions for the AC connection.....	23

5.4.2 AC connection	23
5.4.3 Earthing protection	28
5.4.4 Residual current protection	29
5.4.5 Overvoltage category	29
5.4.6 AC circuit breaker	30
5.5 DC connection	31
5.5.1 Conditions for the PV generator (DC)	31
5.5.2 Assembling the DC connectors	32
5.5.3 Disassembling the DC connectors	34
5.5.4 Connecting the PV array	36
6 Communication	38
6.1 Monitoring system	38
6.2 Communication Connection	39
6.2.1 Communication Overview	39
6.2.2 Connection type for RS485-HD	40
6.2.3 Connection type for RS422	43
6.3 Updating the firmware via RJ45	47
6.4 Communication with a third party monitoring equipment	47
7 Commissioning	48
7.1 Electrical checks	48
7.2 Mechanical checks	49
7.3 Start-Up	49
8 Disconnecting the Inverter from Voltage Sources	50
9 Operating	51
9.1 Overview of the control panel	51
9.2 LED indicators	52
9.3 Display messages	53

9.4 Display	55
9.4.1 Overview of menu structure	55
9.4.2 Initial page.....	56
9.4.3 Unlocking page	56
9.4.4 Home page.....	56
9.4.5 Operation information	57
9.4.6 Main menu	58
9.4.7 Historical data	58
9.4.8 Event log	59
9.4.9 Date &Time setting	59
9.4.10 Language setting.....	60
9.4.11 Contrast setting.....	60
9.4.12 Safety regulations setting.....	61
9.4.13 Overload Setting	62
9.4.14 Active power control	62
9.4.15 Reactive power control	62
9.4.16 PV Mode Setting	63
9.4.17 EEG Setting.....	63
9.4.18 Communication Setting.....	64
9.4.19 Device information	64
9.4.20 Clear the historical data	65
10 Technical data.....	66
10.1 DC input data	66
10.2 AC output data	67
10.3 Safety protection	68
10.4 General data	69
10.5 Power reduction.....	71
10.6 Tools and torque	72

11 Troubleshooting	73
12 Maintenance	75
12.1 Replace the fuse.....	75
12.2 Cleaning the contacts of the DC switch	76
12.3 Cleaning the heat sink	76
12.4 Maintaining the fans	76
13 Recycling and disposal	78
14 Warranty	78
15 Contact	79

1 About this manual

General Notes

The Novergy IGPB 34KW is a transformerless three-phase inverter with two MPP trackers. It converts the direct current (DC) from a photovoltaic (PV) array to grid-compliant alternating current (AC) and feeds it into the utility grid.

1.1 Validity

This manual describes the mounting, installation, commissioning and maintenance of the following Novergysolar inverter: IGPB 34KW.

Observe all documentation that accompanies the inverter. Keep them in a convenient place and available at all times.

1.2 Target group

This manual is for qualified electricians only who must perform the tasks exactly as described.

All persons installing inverters must be trained and experienced in general safety which must be observed when working on electrical equipment. Installation personnel should also be familiar with local requirements, rules and regulations.

1.3 Symbols used in this manual

The safety precautions and general information used in this manual are as follows:

**DANGER**

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

**WARNING**

WARNING indicates a hazardous situation which, if not avoided, can result in death or serious injury.

**CAUTION**

CAUTION indicates a hazardous situation which, if not avoided, can result in minor or moderate injury.

NOTICE

NOTICE indicates a situation which, if not avoided, can result in property damage.




INFORMATION provides tips which are valuable for the optimal installation and operation of the inverter.

2 Safety

2.1 Intended use

1. IGPB 34KW is suitable for indoor and outdoor use.
2. IGPB 34KW must only be operated with PV arrays (PV modules and cabling) of protection class II, in accordance with GB/T 20047.1. Do not connect any sources of energy other than PV modules to the inverter.
3. IGPB 34KW inverters can only be connected with photovoltaic arrays whose equivalent capacitance to ground is less than $2.0\mu\text{F}$.
4. When the PV modules are exposed to light, a DC voltage is supplied to this equipment.
5. This inverter supports the grid forms shown in detail as follows: TN-S, TN-C, TN-C-S, TT. In terms of TT, the effective value of U_{N_PE} must be less than 20V.



2.2 Safety standards

IGPB 34KW complies with the European standard of low voltage appliance 2006/95/EC and EMC standard 2004/108/EC and it has a CE mark on the label.

2.3 Important safety information

DANGER

Danger to life due to high voltages of the PV array!

When exposed to sunlight, the PV array generates dangerous DC voltage which is present in the DC conductors and the live components of the inverter. Touching the DC conductors or the live components can lead to lethal electric shocks. If you disconnect the DC connectors from the inverter under load, an electric arc may occur leading to electric shock and burns.

- Do not touch non-insulated cable ends.
- Do not touch the DC conductors.
- Do not touch any live components of the inverter.
- Have the inverter mounted, installed and commissioned only by qualified persons with the appropriate skills.
- If an error occurs, have it rectified by qualified persons only.
- Prior to performing any work on the inverter, disconnect it from all voltage sources as described in this document (see Section 8 "Disconnecting the Inverter from Voltage Sources", page 50).

WARNING

Risk of injury due to electric shock and fire caused by high leakage current!

- The inverter must be reliably grounded in order to protect property and personal safety.

 **CAUTION**

Risk of injury due to hot heat sink!








- The heat sink may get hot during operation. Do not touch!

 **CAUTION**

Grounding the PV array!

- Comply with local regulations for grounding the PV array. We suggest that the frames of the PV modules must be reliably grounded.
- Do not ground any of the terminals of the PV module strings.

2.4 Symbols on the type label

Symbol	Explanation
	Beware of high voltage and operating current. The inverter operates at high voltage and current. Work on the inverter must only be carried out by skilled and authorized electricians.
	Beware of hot surfaces. The inverter can get hot during operation. Avoid contact during operation.
	Do not dispose of this inverter with household waste. For more information on disposal, please refer to Section 13 “Recycling and disposal”.
	CE mark. The inverter complies with the requirements of the applicable EC guidelines.
	Capacitors discharge. Before opening the covers, the inverter must be disconnected from the grid and PV array. Wait at least 5 minutes to allow the energy storage capacitors to fully discharge.
	Refer to the manual accompanying the inverter.
	Risk of danger, warning and caution. Safety information important for human safety. Failure to observe the safety information in this manual may result in injury or death.

2.5 Basic safety protection


We provide the following safety protection:

- 1) Over-voltage, under-voltage protection;
- 2) Over-frequency, under-frequency protection;
- 3) Over-temperature monitoring;
- 4) Residual current monitoring;
- 5) Insulation monitoring;
- 6) Active islanding protection (non-utility type);
- 7) Low voltage ride through (Utility type);
- 8) Output DC component test.


3 Unpacking

3.1 Scope of delivery


Object	Description	Quantity
A	Inverter	1
B	Wall mounting bracket	1
C	Mounting accessory kit	1
D	Documentation	1
E	DC connector(positive)	8
F	DC connector(negative)	8




A



B



C



D



E



F

3.2 Checking the delivery


Check the delivery for completeness and visible external damage, such as cracks in the enclosure or in the display. Inform the responsible shipping company immediately or contact your distributor if anything is damaged or missing.

4 Mounting


4.1 Ambient conditions

1. The mounting location must be inaccessible to children.
2. The mounting location should be dry, freely and safely accessible at all times without the need for any auxiliary equipment.
3. Mount the inverter in areas where it cannot be touched inadvertently.
4. The mounting method and location must be suitable for the inverter's weight and dimensions.
5. The ambient temperature should be below 40°C to ensure optimal operation.
6. In living areas, do not mount the unit on plasterboard walls or similar to avoid audible vibrations. The inverter can make noises when in use which may be perceived as a nuisance in a living area.
7. Observe the minimum clearances to walls, other inverters, or objects as shown in the diagram in order to ensure sufficient heat dissipation and sufficient space for maintaining the inverter.

Direction	Min. clearance for multiple inverters	Min. clearance for a single inverter
above	200mm	200mm
below	500mm	500mm
sides	600mm	600mm
spacing	1000mm	




clearances for one inverter



Recommended clearances for multiple inverters installation

- Avoid exposing the inverter to direct sunlight, rain and snow to ensure optimal operation and extend service life. It is recommended to mount the inverter under the shaded site of the building or to mount an awning or a protection cover above the inverter.




- Do not put any objects above the inverter.

4.2 Mounting location

DANGER

Danger to life due to fire or explosion!

- Do not mount the inverter on flammable construction materials.
- Do not mount the inverter in areas where flammable materials are stored.
- Do not mount the inverter in areas where there is a risk of explosion.



1. Mount the inverter vertically or tilted backwards at a maximum angle of 15° .
The wall should be suitable for the weight of the inverter over a long time.
2. Never mount the inverter tilted forward or sideways.
3. Never mount the inverter horizontally.
4. Mount the inverter at eye level to allow operating status to be read at all times.
5. The electrical connection area must point downwards.

4.3 Mounting the inverter with the wall bracket



CAUTION

Risk of injury when lifting the inverter, or if it is dropped!

When mounting, at least two persons are needed, take into account that the inverter weighs approximately 58kg.

Mounting procedure:

1. Use the wall bracket as a drilling template and mark the positions of the drill holes on the wall, drill 6 holes as required using a drill with $\text{Ø}10$ mm bit. The holes must be approximately 70 mm deep. Keep the drill perpendicular to the wall, and hold the drill steady to avoid tilted holes.




CAUTION


- Before inserting the wall plugs, measure the depth and distance of the holes.
- If the measured values do not meet the hole requirements, redrill the holes.

2. Insert six wall plugs into the holes in the wall with a rubber hammer and fix the wall bracket to the wall by tightening six hexagon screws, using a socket wrench


SW10.




3. Mount the inverter onto the wall bracket.




If the inverter is to be transported and lifted with a crane, screw two eye bolts M10 (provided by installer) into the threads which are located on the top of the inverter.



Check if the hook on the top of the wall bracket is in position after mounting the inverter onto the wall bracket.



4. Secure the inverter to the wall bracket using four M5 screws on both sides to prevent the inverter from accidentally slipping off. Screwdriver type: T25, Torque: 2.5Nm.



- Dismantle the inverter in reverse order.

5 Electrical Connection

5.1 Safety

DANGER

Danger to life due to high voltages of the PV array!

When exposed to sunlight, the PV array generates dangerous DC voltage which is present in the DC conductors and the live components of the inverter. Touching the DC conductors or the live components can lead to lethal electric shocks. If you disconnect the DC connectors from the inverter under load, an electric arc may occur leading to electric shock and burn.

- Do not touch non-insulated cable ends.
- Do not touch the DC conductors.
- Do not touch any live components of the inverter.
- Have the inverter mounted, installed and commissioned only by qualified persons with the appropriate skills.
- If an error occurs, have it rectified by qualified persons only.
- Prior to performing any work on the inverter, disconnect it from all voltage sources as described in this document (see Section 8 "Disconnecting the Inverter from Voltage Sources", page 50).

WARNING

Risk of injury due to electric shock!

- All electrical connections must be connected in accordance with national and local electrical standards, and obtaining approval from local grid operator.

WARNING

Risk of injury due to electric shock!

- The external protective earthing conductor is connected to the inverter's protective earthing terminal through an AC terminal block, ensure the connection is reliable.
- When connecting, connect the AC terminal block first to ensure the inverter earthing and then connect the DC inputs.
- When disconnecting, disconnect the DC inputs first and then disconnect the AC terminal block.

NOTICE

Damage to the inverter due to electrostatic discharge!


- Touching electronic components can cause damage to or destroy the inverter through electrostatic discharge.
- Ground yourself before touching any component inside.

5.2 System layout of inverters without integrated DC-switch


Local standards or codes may require that PV systems are fitted with an external DC-switch. The DC-switch must be able to safely disconnect the open-circuit voltage of the PV array plus a safety reserve of 20%.

Every MPPT input must pass the DC-switch, so that it is isolated from the DC side of the inverter.

We recommend the following electrical connection:



5.3 Overview of the electrical connection area



Position	Designation
A	DC-switch (optional)
B	DC connectors, input 1
C	DC connectors, input 2
D	COM 2 (for connecting the monitoring device)
E	External protection earthing terminal
F	COM 1 (for connecting the monitoring device)
G	AC output

5.4 AC connection

⚠ DANGER

Danger to life due to high voltages in the inverter!


- Before establishing the electrical connection, ensure that the AC circuit-breaker is switched off.

5.4.1 Conditions for the AC connection

Cable Requirements

The grid connection is established using five conductors (L1, L2, L3, N, and PE).

We recommend the following specifications for copper wire.



No.	Description	Value
A	External diameter	19...28 mm
B	Conductor cross-sectional area	10...25mm ²
C	Stripping length of the insulated conductors	16 mm
D	Stripping length of the cable's outer sheath	Maximum. 80 mm

The PE insulated conductor must be at least 5 mm longer than the L and N conductors

Notes: Larger cross-sections should be used for longer cables.

The conductor cross-section should be dimensioned to avoid power loss in cables exceeding 1% of rated output power.

The maximum cable lengths depend on the conductor cross-section as follows:

Conductor cross-section	Maximum cable length
	IGPB 34KW
10mm ²	22 m
16mm ²	36 m
25mm ²	56 m

The required conductor cross-section depends on the inverter model, ambient temperature, routing method, cable type, cable losses, applicable installation requirements (installation location) of the country of installation, etc.

NOTICE

Damage to the inverter due to electrostatic discharge!

- Touching electronic components can cause damage to or destroy the inverter through electrostatic discharge.
- Ground yourself before touching any component inside.

NOTICE

Damage to the seal of the cover by opening the cover of the inverter in sub-zero conditions!

- When opening the cover of the inverter in sub-zero conditions, the water proof sealing of the cover may be damaged. This can lead to moisture entering the inverter.
- Do not open the inverter at ambient temperatures lower than -5°C .
- Do not open the inverter if a layer of ice has formed on the seal of the cover in sub-zero condition, remove it prior to opening the inverter (e.g. by melting the ice with warm air). Observe the applicable safety regulations.


Procedure:

1. Switch off the AC circuit-breaker and secure it against being inadvertently switched back on.
2. Loosen the screws of the lower cover of the inverter using a screwdriver (type: T25).



Loosen the screws of the lower cover!



- During loosening the screws of the lower cover, it is not necessary to take off the screws, which can remain on the lower cover and will not fall off.




3. Strip the cable insulation as follows:

Strip the cable insulation by 80mm (as D shown), shorten L1, L2, L3 and N, and make them 5mm shorter than PE conductor. Then strip each conductor insulation by 16mm (as C shown).

Insert the bared conductor into the cord end terminal and crimp the contact, customer needs to prepare the cord end terminals in advance.




4. Insert the crimped conductors L1, L2, L3, N and PE into the corresponding AC terminals through the cable gland and tighten the screws on the terminal block, using a flat blade screwdriver (blade size: 1.0 x 5.5mm) with torque 3.0Nm.



NOTICE


Five conductors must be inserted into the corresponding holes of the AC terminal block! Otherwise it may cause damages to the inverter. The warranty does not cover the aforementioned damage.

5. Tighten AC cable gland swivel nut (SW46) by hand. Pre-screw 4 screws in lower cover and tighten them in the sequence (1-2-3-4). Screwdriver type: T25, torque: 2.5Nm.




5.4.3 Earthing protection

If required, the grounding terminal at the right bottom of the inverter can be used to connect a second protective conductor or as equipotential bonding with a screwdriver (Type: T25), torque: 2.5Nm.



Information on earthing components is shown in the table below:



Information on grounding components :

No.	Position	Description
1	M5 screw	Delivered with the inverter
2	OT terminal (M5)	Provided by installer
3	Yellow/green earthing cable	10-25mm ²

5.4.4 Residual current protection

The inverter is equipped with a residual current monitoring unit (RCMU) comprising a differential current sensor and relevant detecting circuits, which fulfills the requirements of DIN VDE 0100-712 (IEC60364-7-712:2002).

Therefore an external residual current device (RCD) is not required. If an external RCD needs to be installed because of local regulations, an RCD type A or type B can be installed as an additional safety measure.

The residual current monitoring unit (RCMU) integrated in the inverter detects both AC & DC currents. The function of the residual current monitoring unit (RCMU) has been tested in accordance with IEC 62109-2.



Refer to the following information in case an external RCD is needed!

- If an external residual current device (RCD) is required in a TT or TN-S system, install a residual current device which activates at a residual current of 200mA or higher.
- For each connected inverter, a rated residual current of 200mA has to be provided. The rated residual current of the RCD must be equal to at least the sum of the rated residual currents of the connected inverters. That means that, if, for example, two transformerless inverters are connected, the rated residual current of the RCD must be at least 400mA.

5.4.5 Overvoltage category

The inverter can be deployed in grids of overvoltage category III or lower, as defined under IEC 60664-1. This means that it can be directly connected to the grid-connection point in a building. In installations involving long outdoor cable routing, additional overvoltage-reducing measures must be taken so that the grid overvoltage category at the connecting point is reduced from category IV to III.

5.4.6 AC circuit breaker

DANGER

Danger to life due to fire!

- You must protect each inverter with an individual AC circuit breaker in order to ensure that the inverter can be disconnected safely.

No consumer load should be applied between the AC circuit breaker and the inverter. Use dedicated circuit breakers with load switch functionality for load switching. The selection of the AC circuit breaker rating depends on the wiring design (wire cross-section area), cable type, wiring method, ambient temperature, inverter current rating, etc. Derating of the AC circuit breaker rating may be necessary due to self-heating or if exposed to heat.

The maximum output current of the inverters can be found in the following table.

Type	IGPB Pro 34KW
Max. output current	48A
Recommended fuse type gL/gG or comparable automatic circuit breaker rating	63A

5.5 DC connection

DANGER

Danger to life due to high voltage in the inverter!

- Before connecting the PV generator, ensure that the DC switch is switched off and that it cannot be reactivated.
- Do not disconnect the DC connectors under load.

5.5.1 Conditions for the PV generator (DC)

- PV modules of the connected strings must be of:
 - the same type
 - the same number of series-connected PV modules
 - identical alignment
 - identical tilt
- The connection cables of the PV modules must be equipped with the connectors included in the scope of delivery.
- At the DC input of the inverter, the following limits must not be exceeded:


Type	Max. DC voltage*	Max. DC current	Max. short-circuit current
IGPB 34KW	1000V	34A/34A	51A/51A

*) On the coldest day based on statistical records, the open-circuit voltage of the PV array must never exceed the maximum input voltage of the inverter.

- The positive connection cables of the PV modules must be equipped with the positive DC connectors.
- The negative connection cables of the PV modules must be equipped with the negative DC connectors.
- At an ambient temperature over 10°C, the open-circuit voltage of the PV strings must not exceed 90% of the maximum DC input voltage of the inverter. This prevents the voltage from exceeding the maximum DC input voltage of the inverter at lower ambient temperatures.

5.5.2 Assembling the DC connectors

Assemble the DC connectors as described below. Observe the correct polarity. The DC connectors are marked with the symbols "+" and "-".



Cable requirements :

The cable must be of type PVI-F, UL-ZKLA or USE2 and comply with the following properties:

- ✧ External diameter: 5 mm to 8 mm
- ✧ Conductor cross-section: 2.5 mm² to 6 mm²
- ✧ Number of copper conductors: at least 7
- ✧ Nominal voltage: at least 1000V


DANGER

Danger to life due to high voltages on DC conductors!
When exposed to sunlight, the PV array generates dangerous DC voltage which is present in the DC conductors. Touching the DC conductors can lead to lethal electric shocks.


- Cover the PV modules.
- Do not touch the DC conductors.

Proceed as the follows:


1. Strip the cable insulation as shown in the picture below.






2. Insert the stripped cable all the way into the DC connector.



3. Press the clamping bracket down until it audibly snaps into place.



4. Ensure that the cable is correctly positioned:

Result	Measure
<p>If the stranded wires are visible in the chamber of the clamping bracket, the cable is correctly positioned.</p> 	<ul style="list-style-type: none"> • Proceed to step 5.
<p>If the stranded wires are not visible in the chamber, the cable is not correctly positioned.</p> 	<ul style="list-style-type: none"> • Release the clamping bracket with a flat-blade screwdriver (blade width: 3.5 mm).  <ul style="list-style-type: none"> • Remove the cable and go back to step 1.

5. Push the swivel nut up to the thread and tighten the connector (SW15, torque: 2.0Nm).



5.5.3 Disassembling the DC connectors

⚠ DANGER

Danger to life due to high voltages on DC conductors!

When exposed to sunlight, the PV array generates dangerous DC voltage which is present in the DC conductors. Touching the DC conductors can lead to lethal electric shocks.


- Cover the PV modules.
- Do not touch the DC conductors.

Proceed as the follows:


1. Unscrew the swivel nut.




2. To release the connector, insert a flat-blade screwdriver (blade width: 3.5 mm) into the side catch mechanism and lever out.




3. Carefully pull out the DC connector.



4. Release the clamping bracket. To do so, insert a flat-blade screwdriver (blade width: 3.5 mm) into the clamping bracket and lever out.



5. Remove the cable.



5.5.4 Connecting the PV array

NOTICE

The inverter can be destroyed by overvoltage!

If the voltage of the PV module exceeds the maximum DC input voltage of the inverter, it can be destroyed due to overvoltage. All warranty claims become void.


- Do not connect strings with an open-circuit voltage greater than the maximum DC input voltage of the inverter.
- Check the design of the PV system.

Procedure:

1. Ensure that the AC circuit breaker is switched off and ensure that it cannot be accidentally reconnected.
2. Ensure that the DC switch is switched off and ensure that it cannot be accidentally reconnected.
3. Ensure that there is no ground fault in the PV array.
4. Check whether the DC connector has the correct polarity.

If the DC connector is equipped with a DC cable having the wrong polarity, the DC connector must be re-connected in accordance with the right polarity.


5. Ensure that the open-circuit voltage of the PV array does not exceed the maximum DC input voltage of the inverter.
6. Connect the assembled DC connectors to the inverter until they audibly snap into place.
7. Ensure that all DC connectors are securely in place.




NOTICE

Damage to the inverter due to moisture and dust penetration!
Seal the unused DC inputs with sealing plugs so that moisture and dust cannot penetrate the inverter.

8. The inverter is only properly sealed when all the unused DC inputs are closed with sealing plugs.




6 Communication



6.2.2 Connection type for RS485-HD

Move slide switch CN901 to the position RS485-HD when using RS485-HD communication type, as shown in the figure below.




When RJ45 is employed as the communication port for RS485-HD, the pin assignment of RJ45 is as follows:

Pin1----- RS485_A	
Pin2----- RS485_B	
Pin3----- NC	
Pin4----- GND	
Pin5----- GND	
Pin6----- NC	
Pin7----- +7V	
Pin8----- +7V	


When the terminal block is employed as the communication port for RS485-HD, the pin distribution of terminal block is as follows:

cable 485	pin of terminal block
RS485_A	A
RS485_B	B
GND	GND


When connecting one inverter, you need to connect the terminal resistance to the bus by switching CN909 to the ON position as shown in the figure below (Switch CN909 to ON, CN910 to OFF):



When connecting multiple inverters, please move the terminal resistance slide switch (CN909) on the inverter which at the end of the bus to ON and all switch resistance slide switches of the inverters in between to OFF as shown in the figure below:




Inverter in the Middle



Inverter at the end of the bus


6.2.3 Connection type for RS422

Firstly, switch the slide switch CN901 to RS422 as shown in the figure below:



Ports except port RJ45 are not allowed to be connected when employing RS422 communication mode.

The pin information for RJ45 interface is shown in the table below:


Pin1----- TX_RS485A	
Pin2----- TX_RS485B	
Pin3----- RX_RS485A	
Pin4----- GND	
Pin5----- GND	
Pin6----- RX_RS485B	
Pin7----- +7V	
Pin8----- +7V	

The cable pin assignment shall comply with the EIA/TIA568A or 568B standard. When using outdoors you shall use the UV resistant cable.



NOTICE

Damage to the inverter due to electrostatic discharge!
Ground yourself before touching any component inside the inverter to avoid damage to the components inside the inverter by electrostatic discharge.



When Connecting a single inverter, you shall set the terminal resistance of the both the slide switches CN909 and CN910 to ON as shown in the figure:



When connecting multiple inverters, you shall connect the matched resistance at the bus terminal. Switch both the slide switches CN909 and CN910 on the inverter at the end of the bus to ON as shown in the figure below:



Inverter in the Middle




Inverter at the end of bus

NOTICE


Damage to the inverter due to moisture and dust penetration!
Make sure the waterproof connectors of the communication interface are securely tightened.

Connecting procedure for RJ45 connection:


1. Loosen the swivel nut of M25 cable gland for COM1, take out the filler plug in the sealing insert:




2. Guide the network cable through the cable gland and connect it to the RJ45 socket on the communication board.



3. A cable tie can be used to prevent the network cable from loosening.



4. Tighten the cable gland swivel nut of (SW29) by hand.




Disassemble the network cable in a reversed order.

Operating steps for terminal blocks connection is identical to that of RJ45 connection, please refer to the steps above.

6.3 Updating the firmware via RJ45

If you have to update the firmware, use a screwdriver (Type: T25) to unscrew the 4 screws located on the lower cover and update firmware through RJ45 socket.



6.4 Communication with a third party monitoring equipment

IGPB 34KW supports communication with third party monitoring equipment such as Metecontrol, Solar-Log etc. For detailed operation method please refer to operation manual of the corresponding third party monitoring equipment.

7 Commissioning

WARNING

Risk of injury due to incorrect installation!

We strongly recommend carrying out preliminary checks before commissioning to avoid possible damage to the unit caused by faulty installation.

7.1 Electrical checks

WARNING

Danger to life due to the presence DC-Voltage!

- Only touch the insulation of the PV array cables.
- Do not touch parts of the substructure and frame of PV array.
- Wear personal protective equipment such as insulating gloves.

WARNING

Danger to life due to the presence of AC-Voltage!

- Only touch the insulation of the AC cables.
- Wear personal protective equipment such as insulating gloves.

Carry out the main electrical checks as follows:

1. Check PE connection: ensure the inverter has a reliable earth connection.
2. Check the DC voltage values: check that the DC voltage of the strings does not exceed the permitted limits.
3. Check the polarity of the DC voltage: make sure the DC voltage has the correct polarity.
4. Check the PV string insulation to earth: make sure that the insulation resistance to ground is greater than 1 MOhm.
5. Check the grid voltage: check that the grid voltage at the point of connection of the inverter within the permitted values.

7.2 Mechanical checks

Carry out the main mechanical checks to ensure the IP protection level of the inverter:

1. Ensure that the lower cover has been securely screwed in place.
2. Use sealing caps for tight sealing of unused DC input connectors.
3. Make sure the RS485/RS422 connection has been connected securely.
4. Ensure that the cable glands have been securely screwed in place.

7.3 Start-Up

After finishing the electrical and mechanical checks, switch on the AC circuit breaker and DC-switch in turn. The inverter will start up automatically. Usually there are three statuses during operation:

Waiting: When the initial voltage of the strings is greater than the minimum DC input voltage but lower than the start-up DC input voltage, the inverter is waiting for sufficient DC input voltage and cannot feed power into the grid.

Checking: When the initial voltage of the strings exceeds the start-up DC input voltage, the inverter will check feeding conditions at once. If there is anything wrong during checking, the inverter will switch to the "Fault" mode.

Normal: After checking, the inverter will switch to "Normal" state and feed power into the grid.

During periods of little or no sunlight, the inverter may continuously start up and shut down. This is due to insufficient power or input voltage generated by the PV array. If this fault occurs often, please call service.



Quick Troubleshooting!

If the inverter is in "Fault" mode, refer to Section 11 "Troubleshooting" in the manual.

8 Disconnecting the Inverter from Voltage Sources

DANGER

Danger to life due to high voltages!


The capacitors in the inverter take 5 minutes to discharge.

- Wait 5 minutes before opening the cover.


Before performing any work on the inverter, disconnect it from all voltage sources as described in this section. Always adhere strictly to the prescribed sequence.

Procedure :

1. Disconnect the AC circuit breaker and secure against reconnection.
2. Disconnect the DC-switch and secure against reconnection.
3. Use a current clamp meter to ensure that no current is present in the DC cables.
4. Release and remove all DC connectors. Insert a flat-blade screwdriver or an angled screwdriver (blade width: 3.5 mm) into one of the slide slots and pull the DC connectors out downwards. Do not pull on the cable.



5. Loosen the screws of the lower cover using a screwdriver (T25) and remove the 4 screws.
6. Use a suitable measuring device to check that no voltage is present at the AC screw terminal block between L and N, L and PE, then use a blade screw driver (blade size: 1.0 x 5.5mm) to loosen the screws on the AC terminal block.
7. Unscrew the screws of the terminal block and the swivel nut of the cable gland, remove the AC cable.




8. Tighten the swivel nut (SW46) of the cable gland and secure the 4 screws on lower cover using a screwdriver (Type: T25, torque: 2.5 Nm).

9 Operating

9.1 Overview of the control panel

The inverter is equipped with a control panel which includes a liquid crystal display (LCD), three LED indicators and four touch sensing control buttons. You can view the data and set the parameters of the inverter using the buttons on the LCD display.



No.	Description
A	Display
B	(Up button)
C	(Down button)
D	Normal (Green LED)
E	Fault (Red LED)
F	Communication (Bicolor LED)
G	ESC button
H	↵ (Enter button)

9.2 LED indicators

The inverter is equipped with three LED including “green”, “red” and “bicolor” which provide information about the various operating status of the inverter as follows.

Green LED:

The green LED is lit when the inverter is operating normally.

Red LED:

The red LED is lit when the inverter has stopped feeding power into the grid due to a fault. The corresponding error code will be shown on the display at the same time.

Bicolor LED:

The bicolor LED can blink green or red. It blinks during communication with other devices such as a NovergyManager, Solarlog, etc. The bicolor LED blinks green when the inverter is receiving commands from other devices, and blinks red when the inverter is sending response commands to the other devices.

9.3 Display messages

Along with the various operating states, various messages maybe shown on the display for details, see the following table.

Status	Error code	Description	Causes
Initialization		Waiting	Initial PV voltage is between Min. DC input voltage and start-up DC input voltage of the inverter.
		Checking	The inverter is checking feeding conditions after initial PV voltage exceeds start-up DC input voltage of the inverter.
		Reconnect	The inverter is checking feeding conditions after the last fault has been solved.
Normal		Normal	The inverter is operating normally.
Fault	1	Communication fails between M-S	Communication between the master and slave MCU has failed.
	2	EEPROM R/W Fail	Reading or writing of EEPROM fails
	3	Relay Check Fault	Output relay has failed.
	4	DC injection High	Output DC feed-in exceeds the permitted upper limit.
	8	AC HCT Failure	Output current sensor is abnormal.
	9	GFCI Device failure	GFCI detection circuit is abnormal.
	10	Device Fault	Unknown Error
	11	M-S version unmatched	Different software version between the master and slave MCU.
	33	Fac Fault	The grid frequency lies outside the permitted range.
	34	Vac Fault	The grid voltage is outside the permitted range.
	35	Utility Loss	The utility cannot be detected, which may be caused by no utility, grid disconnected, AC cable damage, fuse broken or island.


Fault	36	Ground Fault	The residual current exceeds the permitted upper limit.
	37	PV Overvoltage	The voltage of the strings exceeds the permitted upper limit.
	38	ISO Fault	The PV generator's insulation resistance to earth is below the permitted value, or the electrical insulation inside the inverter has failed.
	39	Fan Lock	The fan or internal circuit has failed.
	40	Over Temp.	The internal temperature exceeds the permitted value.
	41	Vac differs for M-S	A different value of grid voltage has been detected by the master and slave MCU.
	42	Fac differs for M-S	A different value of grid frequency has been detected by the master and slave MCU.
	43	Ground I differs for M-S	A different value of residual current has been detected by the master and slave MCU.
	44	DC Inj. differs for M-S	A different value of DC feed-in has been detected by the master and slave MCU.
	46	High DC Bus	The voltage of DC Bus exceeds the permitted upper limit.
	49	PV1-SPD failure	PV1-SPD failure
	50	PV1-SPD failure	PV2-SPD failure
	51	FUSE failure	DC side FUSE failure

The latest 10 dated failure reports on the NS protection can be read. An interruption in the supply voltage of 3s does not result in any loss of failure reports (according to VDE-AR-N 4105).

9.4 Display


9.4.1 Overview of menu structure

The diagram is a diagram that shows the switching relations between all pages on the LCD.



9.4.2 Initial page

When the inverter starts up, the LCD will first display an initial page that shows the current safety standard information of the inverter. The page will display for about 5 seconds and then jump to the home page automatically.




9.4.3 Unlocking page





When the backlight of the LCD has turned off, press any key and the unlocking interface prompts. You need to touch the “downward” arrow and “Esc” in sequence to unlock and enter the home page for operation.

9.4.4 Home page

The home page shows some of the most important operational data of inverter such as the output power, daily energy generation, total power generation, an error code, and the power graph etc.



The LCD will switch to standby mode and jump to the home page automatically, and the backlight will turn off when there is no button operation in 30 seconds.

No.	Description
A	Date & Time
B	Output power
C	Daily power generation
D	Total power generation
E	Error code(*), for details see article 9.3
F	Checking countdown
G	Operating status:  waiting,  operating,  fault
H	Trend map of output power from 4:00 to 22:00
I	Load limit Enable Indication 

(*) The operating temperature of the inverter can't be lower than -25°C. The inverter will go into fault mode and stop power generation when the temperature is lower than -25°C. The display will show the error message "Temp. under -25°C".

9.4.5 Operation information

These two pages show the operational information on the AC & DC side of the inverter respectively. Switch between these 3 pages by pressing the “ ” or “ ” button.

Running Info			
A	VacL1 236.1 V	IacL1 46.3 A	D
	VacL2 235.5 V	IacL2 46.5 A	
	VacL3 237.8 V	IacL2 46.1 A	
B	PF 1.00	Phase Leading	E
C	Fac 50.01 Hz	Runt ime 12 h	F

Running Info			
G	Vpv1 645.8 V	Ipv1 25.3 A	I
	Vpv2 638.2 V	Ipv2 26.8 A	
H	Ppv1 16634 W	Ppv2 16653 W	J

No.	Description
A	Grid voltage
B	Power factor
C	Grid frequency
D	Output current

E	Phase, leading or lagging
F	Running time
G	DC input voltage
H	DC input power 1
I	DC input current
J	DC input power 2


9.4.6 Main menu

Press the " ←↓ " button to enter the main menu from the home page.

Press the " " or " " button to select the menu item.

Press the " ←↓ " button to confirm, enter the sub-page chosen.

Press the "ESC" button to return to the home page.



9.4.7 Historical data

Press the " " or " " button to select the "Statistics" item of main menu and press " ←↓ " button to confirm.

Press the " " or " " button to select Daily historical data, Monthly historical data or Yearly historical data.

Press the " ←↓ " button to confirm.

Press the " " button one time to display the previous historical record.

Press the " " button one time to display the next historical record.

Press the "ESC" button to return to the menu.

Statistics	09/11/2013 Day Statistics
Days	Etoday 0.0 KWh
Months	Peak 0 W
Years	Runtime 0 h

9.4.8 Event log

Press the " " or " " button to select the "Event Log" item of main menu and press the "↵" button to confirm.

Press the " " or " " button to check the fault messages.

Press the "ESC" button to return to the main menu.

	Event	Logs
A [1]	12/09/2013 08:45	E12 B
[2]	11/09/2013 17:23	E03
[3]	10/08/2013 15:23	E43
[4]	07/07/2013 13:23	E45
[5]	02/06/2013 12:23	E01

Object	Description
A	Date and time of the fault
B	Error code


9.4.9 Date &Time setting

Enter the sub-menu "Basic Setting" and press the " " or " " button to select the "Date &Time Setting" item of the "Settings" sub-menu and press the "↵" button to confirm.

Use the " " or " " button to set the year, month, day, hour and minute one by one.

Press the "↵" button to confirm.

Press the "ESC" button to return to the Basic Setting page.




9.4.10 Language setting

Enter the sub-menu "Basic Setting" and press the " " or " " button to select the "Language Setting" and press the "↵" button to confirm.
Use the " " or " " to choose the language.

Press the "↵" button to confirm.

Press the "ESC" button to return to the Basic Setting page.




9.4.11 Contrast setting

Enter the sub-menu "Basic Setting" and press the " " or " " button to select the "Contrast Setting" and press the "↵" button to confirm.
Use the " " or " " to choose the LCD contrast.

Press the "↵" button to save.

Press the "ESC" button to return to the Basic Setting page.



9.4.12 Safety regulations setting

Enter the sub-menu "Advanced Setting" and press the "**↵**" button to input the password. The password is required if you want to change some parameters. Please get the correct password from the service engineer. Enter the correct password and "**↵**" to enter the advanced setting sub-menu page.

Then select the "Safety Setting" item and press the "**↵**" button then enter the safety parameters page.

Password	Advanced Setting
Password: 0 0 0 0	Safety Setting Overload Setting Active power control Reactive power control PV Mode Setting EEG Setting

At the safety regulation parameter page, use the " " or " " button to modify the selected parameter and confirm with the "**↵**" button. Then modify the next parameter in turn. Parameter modification is finished after the Enter key is pressed. Press the "ESC" button to cancel.

Safety	Safety
Standard: DE VDE-AR-N 4105 OVP2 : 265.5 V OVP1 : 185.0 V UVP1 : 255.0 V UVP2 : 180.0 V 10Min-Mean : 180.5 V	OFP2 : 54.50 Hz OFP1 : 53.50 Hz UFP1 : 47.50 Hz UFP2 : 45.50 Hz

There are two pages for safety regulation parameters setup. After modifying the last parameter of the first page, the page will automatically jump to the second page.

NOTICE

The safety of the grid may be influenced due to the wrong safety setting!

- The default parameters settings comply with the local regulations.
- Don't change the values of the default safety regulation values unless permitted by the utility provider!


9.4.13 Overload Setting

Enter the sub-menu "Advanced Setting" and press the " " or " " button to select the "Overload Setting" and press the "↵" button to set the status.

Use the " " or " " to choose "Enable" or "Disable".

Press the "↵" button to confirm this function is effective on the inverter.

Press the "ESC" button to return to the Advanced Setting page.




9.4.14 Active power control

Enter the sub-menu "Advanced Setting" and press the " " or " " button to select the "Active power control" and press the "↵" button to set the status.

Use the " " or " " to choose the active power of the status.

Press the "↵" button to confirm this function is effective on the inverter.

Press the "ESC" button to return to the Advanced Setting page.




9.4.15 Reactive power control

Enter the sub-menu "Advanced Setting" and press the " " or " " button to select the "Reactive power control" and press the "↵" button to set the status.

Use the " " or " " to choose the reactive power of the status.

Press the "↵" button to confirm this function is effective on the inverter.

Press the "ESC" button to return to the Advanced Setting page.




9.4.16 PV Mode Setting

Enter the sub-menu "Advanced Setting" and press the " " or " " button to select the "PV Mode Setting" and press the "↵" button to set the status.

Use the " " or " " to choose the PV Mode.

Press the "↵" button to confirm this function is effective on the inverter.

Press the "ESC" button to return to the Advanced Setting page.




9.4.17 EEG Setting

Enter the sub-menu "Advanced Setting" and press the " " or " " button to select the "EEG Setting" and press the "↵" button to set the status.

Use the " " or " " to choose the EEG of the status.

Press the "↵" button to confirm this function is effective on the inverter.

Press the "ESC" button to return to the Advanced Setting page.



9.4.18 Communication Setting

Enter the sub-menu "Communication Setting" and press the " " or " " button to select the address and press the "↵" button to set the modbus communication address.

Use the " " or " " to choose the address.

Press the "↵" button to confirm this function is effective on the inverter.

Press the "ESC" button to return to the menu.

Communication
Device Address : N

9.4.19 Device information


Press the " " or " " button to select the "Device Info" item of the main menu and press the "↵" button to confirm, then you can check the basic information of the device.

Press the "ESC" button to return to the menu.



Device Info
TYPE: ZL Pro 34KW
S/N:1234567890123456
MCU:V1.00
HMI:20U13B20367B.A-1ist02
STD:DE VDE-AR-N 4105

9.4.20 Clear the historical data

Enter the "Advanced Setting" page, enter the correct password, and enter the data clear page.



Press the "↵" button to confirm to clear the historical data. Press the "ESC" button to cancel.



10 Technical data

10.1 DC input data

Type	IGPB 34KW
Rated DC input power(Pdc.r)	34000 W
Max. recommended DC input power	40800 W
Max. DC input voltage	1000 V ⁽¹⁾
Rated DC input voltage	620 V
MPP voltage range	270 ... 950 V
Full load MPP voltage range	500 ... 800 V
Start-up DC input voltage	300 V
Min feed-in DC voltage	270 V
Max. DC input current (input 1/input 2)	34A/34A
Isc PV, absolute max.(input 1/ input 2)	51A/51A
Max. inverter back feed current to the array	0A
Number of MPPT trackers	2
Strings per MPP tracker	4 / 4
Turn on power	25 W
DC-switch	Optional

- (1) When DC input Voltage is higher than 1000V, the inverter will alarm an error.
When DC input Voltage is below 950V, the inverter begins to check and connect to grid.

10.2 AC output data

Type	IGPB Pro 34KW	
Power connection	Three phase	
Rated output power	30000W	
Max. output active power ⁽¹⁾	33000W	
Max. output apparent power ⁽²⁾	33000VA	
Rated grid voltage	3/N/PE, 220/380V	
	3/N/PE, 230/400V	
	3/N/PE, 240/415V	
AC voltage range ⁽³⁾	160 V to 300 V	
Operating range at AC mains frequency 50 Hz ⁽⁴⁾	45 Hz to 55 Hz	
Operating range at AC mains frequency 60 Hz ⁽⁴⁾	55 Hz to 65 Hz	
Max. output current	3×48A	
Power factor	VDE-AR-N 4105	0.85ind - 0.85cap
	Other safety regulations	>0.97 at 20% load, >0.99 at 100% load
Recommended AC circuit breaker	300V,63A, TYPE C circuit breaker	
Total current harmonic wave distortion factor (THD)	<3% (rated power)	
Evening loss	<1 W	
Standby loss	<12 W	

(1) Max. output active power is 30000W for Australia market.

(2) Max. output apparent power is 30000VA for Australia market. (3)The AC voltage range should comply with the local safety standards. (4)The AC frequency range should comply with the local safety standards.

10.3 Safety protection

Type	IGPB 34KW	
Internal overvoltage protection	Integrated	
DC insulation monitoring	Integrated	
DC feed-in monitoring	Integrated	
Grid monitoring	Integrated	
Residual current monitoring	Integrated (according to EN 62109-2)	
Islanding protection	Integrated (Three-phase monitoring)	
EMC immunity	EN61000-6-1, EN61000-6-2	
EMC emission	EN61000-6-3, EN61000-6-4	
Utility interference	EN61000-3-2, EN61000-3-3	EN61000-3-11, EN61000-3-12



INFORMATION

If you choose the standard VDE-AR-N 4105, please refer to information below.

- If a central NS protection device is used for PV power generation station, then the value of the rise-in-voltage protection $U >$ of $1.1U_n$ presented in the integrated NS protection can be changed, but need password.


10.4 General data

Type	IGPB Pro 34KW
Net weight	58 Kg
Dimensions (L×W×D)	710×510×260 mm
Mounting environment	Indoor and Outdoor
Mounting recommendation	Wall bracket
Operating temperature range	-25... +60°C
Max. permissible value for relative humidity (non-condensing)	100%
Max. operating altitude above mean sea level	2000 m
Ingress protection	IP65(Electronics)
	IP55(Fan)
Climatic category	4K4H
Protection class	I (in accordance with IEC 62103)
Overvoltage category	DC input: II, AC output: III
Topology	Transformerless
Feed-in phases	3 phase
Cooling method	Forced air cooling
Noise	< 60 dB(A) @ 1m
Display	240×160Pixels, LCD
Communication interfaces	RS485/RS422

10.5 Efficiency

The operating efficiency is shown for the three input voltages (V_{mppmax} , $V_{dc,r}$ and V_{mppmin}) graphically. In all cases the efficiency refers to the standardized power output ($P_{ac}/P_{ac,r}$). (according to EN 50524 (VDE 0126-13): 2008-10, cl. 4.5.3).

Notes: Values are based on rated grid voltage, $\cos(\phi) = 1$ and an ambient temperature of 25°C.



Max. efficiency, η_{max}	98.5 %
European weighted efficiency, η_{EU}	98.2 %


10.6 Power reduction

In order to ensure inverter operation under safe conditions, the device may automatically decrease power output.

Power reduction depends on many operating parameters including ambient temperature and input voltage, grid voltage, grid frequency and power available from the PV modules. This device can decrease power output during certain periods of the day according to these parameters.

Notes: Values based on rated grid voltage and $\cos(\phi) = 1$.

Power reduction:



10.7 Tools and torque

Tools		Object	Torque
Trox screwdriver, T25		Screws for the lower cover	2.5Nm
		Screws for second protective grounding connection	
		Screws for connecting the inverter and wall bracket	
Flat-head screwdriver, blade size: 1.0×5.5mm		Screw terminal block for AC cable	3.0Nm
Flat-head screwdriver, blade width: 3.5mm		Sunclix DC connector	/
Socket wrench	SW29	swivel nut of the M25 cable gland	4.0Nm
	SW46	swivel nut of the M40 cable gland	7.5Nm
	SW10	Hexagon screw for wall bracket	Hand-tight
Wire stripper		Peel cable jackets	/
Crimping tools		Crimp power cables	/
Hammer drill, drill bit of Ø10		Drill holes on the wall	/
Rubber hammer		Hammer wall plugs into holes	/
Cable cutter		Cut power cables	/
Multimeter		Check electrical connection	/
Marker		Mark positions of drill holes	/
ESD glove		Wear ESD glove when opening the inverter	/
Safety goggle		Wear safety goggle during drilling holes	/
Anti-dust respirator		Wear anti-dust respirator during drilling holes	/

11 Troubleshooting

When the PV system does not operate normally, we recommend the following solutions for quick troubleshooting. If a fault happens, the red LED will light up. The corresponding causes are described in Section 9.3 "Display Messages". The corresponding corrective measures are as follows:

Object	Error Code	Corrective measures
Resumable Fault	38	<ul style="list-style-type: none"> •Check the PV generator's insulation to earth, make sure that the insulation resistance to earth is greater than 1MΩ; Otherwise, make a visual inspection of all PV cables and modules. •Make sure the earth connection of the inverter is reliable. <p>If this fault occurs often, contact the service.</p>
	36	<ul style="list-style-type: none"> •Make sure the earth connection of the inverter is reliable. •Make a visual inspection of all PV cables and modules. <p>If this fault is still shown, please call service.</p>
	46	<ul style="list-style-type: none"> •Check the open-circuit voltages of the strings, make sure it is lower than the Max. DC input voltage of the inverter; <p>If the input voltage lies within the permitted range, and the fault still occurs, maybe the internal circuit has broken, please call service.</p>
	37	<ul style="list-style-type: none"> •Check the open-circuit voltages of the strings, make sure it is lower than the Max. DC input voltage of the inverter. <p>If the input voltage lies within the permitted range and the fault still occurs, please call service.</p>
	41, 42 43, 44	<ul style="list-style-type: none"> •Disconnect the inverter from the grid and the PV generator, reconnect them after 3 minutes. <p>If this fault is still being shown, please call service.</p>
	33	<ul style="list-style-type: none"> •Check the grid frequency and observe how often major fluctuations occur. <p>If this fault is caused by frequent fluctuations, try to modify the operating parameters after informing the utility provider first.</p>

Resumable Fault	35	<ul style="list-style-type: none"> •Check the fuse and the triggering of the AC circuit breaker in the distribution box. •Check grid voltage, grid usability. •Check AC cable, grid connection on the inverter. <p>If this fault is still being shown, please call service.</p>
	34	<ul style="list-style-type: none"> •Check the grid voltage and grid connection on the inverter. •Check the grid voltage at the point of connection of the inverter. <p>If the grid voltage is outside the permissible range due to local grid conditions, try to modify the values of the monitored operational limits after informing the electric utility company first.</p>
	49,50	<p>Open the box and check the power distribution, see if the signal cable of PV1-SPD and PV2-SPD has disconnected.</p> <p>If the fault still occurs, please contact the service hotline.</p>
	51	<p>Open the box and check the power distribution, see if the FUSE is damaged.</p>
	40	<ul style="list-style-type: none"> •Check whether the airflow to the heat sink is obstructed. •Check whether the ambient temperature around the inverter is too high.
Permanent Fault	1,2,3,4 8,9,10, 11, 39	<p>Disconnect the inverter from the grid and the PV generator, reconnect them after 3 minutes. If this fault is still being shown, please call service.</p>

12 Maintenance

Normally, the inverter needs no maintenance or calibration. Regularly inspect the inverter and the cables for visible damage. Disconnect the inverter from all power sources before cleaning. Clean the enclosure and display with a soft cloth.

12.1 Replace the fuse

DANGER


Danger to life due to high voltage!

The capacitors in the inverter take 5 minutes to discharge.

- Wait 5 minutes before opening the cover.

Procedure :

1. Disconnect the AC circuit breaker and secure against reconnection.
2. Disconnect the DC-switch and secure against reconnection.
3. Remove all DC connectors.
4. Wait 5 minutes.
5. Loosen the screws of the lower cover using a screwdriver (T25) and remove the lower cover.
6. Check using multimeter to identify the blown fuse and check the corresponding PV strings.
7. Remove the blown fuse and insert the new fuse into the fuse holder.



8. Reassemble the lower cover and restart the inverter.

12.2 Cleaning the contacts of the DC switch

Clean the contacts of the DC switch annually. Perform cleaning by cycling the switch to “1” and “0” positions 5 times. The DC switch is located at the lower left of the enclosure.

12.3 Cleaning the heat sink

CAUTION

Risk of injury due to hot heat sink!

- The heat sink may exceed 70°C during operation. Do not touch the heat sink during operation.
- Wait approx. 30 minutes before cleaning until the heat sink has cooled down.

Clean the heat sink with compressed air, soft brush or vacuum cleaner.

Do not use aggressive chemicals, cleaning solvents or strong detergents.

For proper function and long service life, ensure free air circulation around the heat sink.

12.4 Maintaining the fans

CAUTION

Risk of injury due to hot heat sink!


- The heat sink may exceed 70°C during operation. Do not touch the heat sink during operation.
- Wait approx. 30 minutes before maintenance until the heat sink has cooled down.

CAUTION

Damage to the fan due to compressed air!

- Clean the fan only with a soft brush, a paint brush, or a damp cloth.

This device is equipped with two fans located on the right side. If the fan does not run normally or makes any unusual noise, clean the fans or replace the broken fans. To do so, disconnect the inverter from all power sources, and wait approx. 30 minutes until the inverter has cooled down. Unscrew the fan bracket (Screwdriver type: T25) and remove the fans out of the inverter by pressing on the cable locking hooks of the fans. Loosen the screws securing the fan by a Phillips screwdriver. Then the fan can be cleaned using a soft cloth or a brush or be replaced. After maintenance, reassemble the fans back (Torque: 0.7Nm) and tighten 4 screws on the fan bracket with a screwdriver (Type: T25, torque: 2.5Nm).



13 Recycling and disposal

Dispose of the packaging and replaced parts according to the rules applicable in the country where the device is installed.



Do not dispose the IGPB inverter with normal domestic waste.



INFORMATION

- Do not dispose of the product together with the household waste but in accordance with the disposal regulations for electronic waste applicable at the installation site.

14 Warranty

When the customer needs warranty service during the warranty period, the customer must provide a copy of the invoice, factory warranty card, and ensure the electrical label of the inverter is legible. If these conditions are not met, Novergysolar has the right to refuse to provide with the relevant warranty service.

15 Contact

If you have any technical problems concerning our products, please contact Novergysolar service. We require the following information in order to provide you with the necessary assistance:

- Inverter device type
- Inverter serial number
- Type and number of connected PV modules
- Error code
- Mounting location
- Installation date
- Warranty card

Novergysolar Factory Warranty

If you need any service during warranty, you need to show the copy of invoice and the warranty card, you also need to keep the electrical label of the inverter clean. If not, Novergysolar has the right to reject providing service.

If you have any technical problems concerning our products, please contact us.

Novergy Energy Sol. P. Ltd.

Tel : +91-294-2415488 / 2415487 / 2450467

Email : support@novergy.net / info@novergy.co.in